
PRIME DESIGN

A Safe Fleet Brand






Address: 580 Opperman Drive, Eagan, MN 55123 • Toll Free: 1.8.PRIME.RACK Fax: 651-552-1799 • Email: info@primedesign.net • Website: www.primedesign.net

20.00"

CONTENTS OVERVIEW 1—Rear Rotation Assembly......(Qty 1) 2—Front Rotation Assembly......(Qty 1)

3-Mount Brace.....(Qty 1)




MOUNTING DIMENSIONS



Mounting to Service Body: dimensions are dependent upon Crossbar distances of 6'-8' plus allowance for the Mount Brace from the front of the Utility Rack.

Allow spacing for the Mount Brace, but do not drill or install until Step 9.



6.00 Ft: Drill holes into the Service Body mounting location according to dimensions shown.

Brace Area

10.00"


Rear Lower

7.00 Ft: Drill holes into the Service Body mounting location according to dimensions shown.

Brace Area

10.00"

Rear Lower



Prime Design Limited Warranty. Seller's sole and exclusive warranty (and Buyer's sole and exclusive remedy and Seller's entire liability for any breach thereof) with respect to the Goods is set forth in the Limited Warranty document available at primedesign. net/warranty-liability (the "Prime Design Limited Warranty"). • TM & © 2021 PRIME DESIGN. PROTECTED BY ONE OR MORE OF THE FOLLOWING PATENT NO.'s 6427889, 6764268, 6971563, 8991889, 9415726, 9506292, 9481313, 9776476, 9796340, 10470565, 10486608, 10501022 AND OTHER PATENTS PENDING

