# **DeployPro**



For Ram ProMaster





# Easy to Use

Integrated hydraulic cylinder for controlled ladder deployment and gas assisted lift for easy stowing



# Improve productivity

Users feet stay safely on the ground, eliminates the need to climb on bumper or tire



# **Enhance Safety**

Stow and deploy ladders from the rear of the vehicle, safely away from potential road hazards



### **Quick Installation**

Rack assembly comes pre-assembled for a Quick up-fit with adjustable ladder support bars to fit your fleet vehicle and various ladders



# **DeployPro**



A Safe Fleet Brand

# For Ram ProMaster





**DeployPro** 

Model	Operation	Mount	Ladder Support Bars Spacing	Drop Distance	Carrying Capacity	Length	Width	Weight			
DPS-8001	Removable Handle	Crossbars*	5′ - 8′	90"	75 lbs.	119"	24"	129 lbs.			
Optional Accessories											
PLR-8229	Lock-N-Go ladder clamp system for extension ladders							7 lbs.			
PLR-8234	Lock-N-Go ladder clamp system for step or combination ladders							7 lbs.			

<sup>\*</sup>Vehicle mounting interface not included; must purchase separately. Standard DeployPro System includes interface and hardware for mounting to the crossbars of a compatible Prime Design ErgoRack. Other mounting solutions are possible; customer supplied hardware may be required.

# DPS-8001 + HBR-E-PM-M

# **Vehicle Interface**

# **ErgoRack Options**

Vehicle	Wheelbase	Roof Height	ErgoRack Model	Streetside Feature	Curbside Feature	Weight
RAM ProMaster	All	Low or High	HBB-PM-M	Base	Base	45 lbs.
			HBR-E-PM-M	Base	Rotation	100 lbs.

<sup>\*</sup>with Factory Channels

DeployPro mounts to ErgoRack crossbars on the Base feature side

**Note:** Contact Prime Design customer service for application specific questions. Check the vehicle manufacturer's recommendation for roof capacity weight limits. A wide range of accessories are available including conduit carriers, light holders, and more.

### ML-7.2-4094 / Rev D / 2-11-2023



<sup>\*\*</sup>without Factory Channels