# **DeployPro**



For Sprinter







## Easy to Use

Integrated hydraulic cylinder for controlled ladder deployment and gas assisted lift for easy stowing



## Improve productivity

Users feet stay safely on the ground, eliminates the need to climb on bumper or tire



## **Enhance Safety**

Stow and deploy ladders from the rear of the vehicle, safely away from potential road hazards



#### **Quick Installation**

Rack assembly comes pre-assembled for a Quick up-fit with adjustable ladder support bars to fit your fleet vehicle and various ladders





# **DeployPro**

# PRIME DESIGN

# For Sprinter









# **ErgoRack Options**

Vehicle	Wheelbase	Roof Height	ErgoRack Model	Streetside Feature	Curbside Feature	Weight
Sprinter	All	Standard or High	HBB-SP-M*	Base	Base	36 lbs.
			HBR-E-SP-M*	Base	Rotation	91 lbs.
			HBB-SPX-M**	Base	Base	21 lbs.
			HBR-E-SPX-M**	Base	Rotation	76 lbs.

<sup>\*</sup>with Factory Channels

DeployPro mounts to ErgoRack crossbars on the Base feature side

**Notes:** Contact Prime Design customer service for application specific questions. Check the vehicle manufacturer's recommendation for roof capacity weight limits. A wide range of accessories are available including conduit carriers, light holders, and more.

#### ML-7.2-4093 / Rev D / 3-30-2023

Copyright ©2023 Safe Fleet and its subsidiaries. All rights reserved. No part of this publication may be reproduced by any means without written permission from Safe Fleet. The information in this publication is believed to be accurate. However, Safe Fleet does not make any representation or warranty to that effect and does not assume responsibility for any consequences resulting from use of such information. Revisions or new editions of the publication may be issued (or not issued) in our discretion to incorporate such changes.







<sup>\*\*</sup>without Factory Channels