

PRIME DESIGN





Address: 580 Opperman Drive, Eagan, MN 55123 • Toll Free: 1.8.PRIME.RACK Fax: 651-552-1799 • Email: info@primedesign.net • Website: www.primedesign.net



4—Rear Drive Shaft Right Hand, 50.00"	(Qty 1)		M	
				0
5—Connecting Bar48.00"	(Qty 1)	9		9
6—Front Drive Shaft B Version, 35.75"	(Qty 1)	0.	9	• • •)
HKT-8163-Rotation Hardware Kit				
Clevis Pin (1X)	M8 x 50MM (4X)		3⁄s" x 2.2	25" (2X)
Cotter Pin (1X) M8 x 25MM (1X)				
	M8 Lock Nut (5X)	3/8" Lock Nut (2X)	⁵ / ₁₆ " Flat Washer (10X)	3%" Flat Washer (4X)
1.00" Sealing Stickers (16X)			Anti-Seize	e (1X)
			Lubricant (1X)	
HKT-0055-Rotation Hardware Kit				
Neoprene Washer (5X)	Fender V	Vasher (5X)	⁵⁄₁₅" Seal Washer (5X)	5∕16" Flat Washer (2X)
M8 x 65M	M (1X)		M8 x 70MM	(4X)
M8 Lock Nut (6X)	M8 x 30MM (1X)		Anti-Seize	(1X)

MOUNTING DIMENSIONS



Mounting to Service Body: dimensions are dependent upon Crossbar distances of 6'-8' plus allowance for the Mount Brace from the front of the Utility Rack.

Allow spacing for the Mount Brace, but do not drill or install until Step 9.

