



PRIME DESIGN™

A Safe Fleet Brand



STANLEY
HRR-E



- 1—FBM-0014 (Qty 1)
Channels with hardware



66" Channels (4X)



End Caps (4X)



Screws (8X)




Top Connector (2X)



Bottom Connector (2X)




Brackets (4X)




Mountings (8X)

M8 Bolt (4X)


- 2—Rear Crossbar Assembly (Qty 1)




- 3—Front Crossbar Assembly (Qty 1)




4—Drive Shaft (Qty 1)
Rear, Right Hand, 50.00"




5—Connecting Bar (Qty 2)
48.00"



6—Front Drive Shaft (Qty 2)
B Version, 35.75"




7—Z Post (Qty 2)
Adjustable, 7.25"




8—L Post (Qty 2)
Gen2, Roller Cap, 9.25"




9—Drive Shaft (Qty 1)
Rear, Left Handed, 50.00"




10—HRR Removeable Handle Assembly (Qty 1)




11—HKT-8163 (Not called out in Overview) (Qty 2)




M8 x 25MM (1X)



M8 x 50MM (4X)




3/8" x 2.25" (2X)




Cotter Pin (1X)




Clevis Pin (1X)




M8 Lock Nut (5X)




3/8" Lock Nut (2X)



5/16" Flat Washer (10X)




3/8" Flat Washer (4X)



1.00" Sealing
Stickers (16X)







Anti-Seize (2X)




Lubricant (2X)



FBM-0014 MOUNTING BRACKETS

INSTALLER NOTE: Mounting Brackets must be disassembled for installation onto the vehicle's roof.







6 Set to distances then torque Mounting Bracket nuts to 80 in-lbs




8 Set to distances then torque Mounting Bracket nuts to 90 in-lbs








CROSSBARS




CROSSBAR ADJUSTMENT




REAR DRIVE SHAFT




CYLINDER HARDWARE




CONNECTING BAR



FRONT DRIVE SHAFT




CONNECTING BAR FASTENERS




L POST

SEE QUICK START GUIDE FOR ADJUSTMENTS




Z POST



SEE QUICK START GUIDE FOR ADJUSTMENTS







LEFT ROTATION ASSEMBLY




REAR DRIVE SHAFT



CYLINDER HARDWARE**CONNECTING BAR****FRONT DRIVE SHAFT****CONNECTING BAR FASTENERS**


L POSTS

SEE QUICK START GUIDE FOR ADJUSTMENTS





Z POSTS

SEE QUICK START GUIDE FOR ADJUSTMENTS



DRIVE SHAFT SEALING



CYLINDER ADJUSTMENT

USAM-HRREPM42-US01 Rev-B 0218