## **ErgoRack**

## PRIME DESIGN

A Safe Fleet Brand

## For Ram ProMaster City





### Easy to use

Deploys with only 2 fingers.



#### Improve productivity

Deploy or stow in less than 20 seconds.



#### **Enhance Safety**

Eliminates slip and fall hazards from climbing on bumper or tire.



#### No Drill Installation

Maintain vehicle warranty and resale value with no holes to drill.



# **ErgoRack**

## RIME DESIGN

A Safe Fleet Brand

## For Ram ProMaster City



VCC-PC11

**Dual Clamp** 



VRR-PC11

**Dual Rotation** 



VCR3-PC11

Clamp / Rotation with 3rd crossbar

Models	Vehicle Wheelbase	Vehicle Height	Street side Feature	Curb side Feature	Weight
VBB-PC11	122 IN	74 IN	End Stop	End Stop	27 lbs
VBC-PC11 VCB-PC11	122 IN	74 IN	End Stop Clamp	Clamp End Stop	42 lbs
VBR-PC11 VRB-PC11	122 IN	74 IN	End Stop Rotation	Rotation End Stop	69 lbs
VCC-PC11	122 IN	74 IN	Clamp	Clamp	57 lbs
VCR-PC11 VRC-PC11	122 IN	74 IN	Clamp Rotation	Rotation Clamp	84 lbs
VRR-PC11	122 IN	74 IN	Rotation	Rotation	112 lbs

Crossbars can be spaced at five or six feet.

Contact Prime Design customer service for application specific questions. Check the vehicle manufacturer's recommendation for roof capacity weight limits.

A wide range of accessories are available including conduit carriers, lighting mounts, and more.

#### Van Crossbar Spacing and Ladder Size Guide

Crossbar Spacing	Step Ladder Size	Extension Ladder Size
5 ft Spacing	8 – 10 ft.	16 – 24 ft.
6 ft Spacing	8 – 12 ft.†	16 – 28 ft.

†12 ft. step ladders may require an extended upper add-on component.